

Marvin Casemaster Stationary Sash Setting Blocks

1. Loose Casemaster sash are sent without sash setting/centering blocks applied. Apply blocks to either sash or frame. Apply blocks at the quarter points on sill and both jambs (frame) or bottom rail and both stiles (sash).
2. Remove backing from adhesive tape on block and install as shown below.

