

# Casemaster Folding Handle Instructions

1. Remove the white plastic shipping cover from roto gear knob.
2. Snap the folding handle cover onto roto gear.
3. Loosen set screw at base of folding handle with a small flat bladed screwdriver.
4. With the sash in a closed and locked position, fit folding handle base over roto gear spline so that the handle will rest in the recess of the cover when folded away.
5. Tighten set screw.

